


43 TELEPRINTER 5-LEVEL PAPER TAPE REAR FRAME AND MISCELLANEOUS
PARTS

1. GENERAL

- 1.01 This section provides information on maintenance parts for the 43 Teleprinter 5-Level Paper Tape Rear Frame and Miscellaneous Assemblies.
- 1.02 Whenever this section is reissued, the reason will be listed in this paragraph.
- 1.03 Part numbers are listed in the index in numerical order and indicate the page on which the parts appear. Parts are not maintenance spares but may be ordered separately for local repair of the Paper Tape Unit.
- 1.04 When ordering replaceable parts or components, unless otherwise specified prefix each part number with the letters "TP" (ie, TP410055).

2. PARTS



Rear Frame and Miscellaneous

3. NUMERICAL INDEX

3.01 Parts listed are not maintenance spares but may be ordered as needed for local repair of major components or terminals.

Part Number	Description and Page Number
182182	Holder, Fuse 2
401628	Bushing 2
412317	Plate, Heatsink 2
430566	Switch 2