## BULLETIN NO. 1031 (ISSUE 3) PARTS - TYPE BAR TAPE PRINTER (MODEL 14) (BELL SYSTEM)

The 104665 set of parts, required for adding a keyboard pulsing contact to a Model 14 printer, consists of the following parts:

78385	Contact (Assem.)
80831	Pulsing Contact (Assem.) 1 (See page 23 of Bulletin No. 1031 for illustration and component parts)
104722	Cable 1