NAVSHIPS 0969-125-0280

(Non-Registered)

TECHNICAL MANUAL

for

ELECTRONIC FREQUENCY CONVERTER CV-2353/U

DEPARTMENT OF THE NAVY
NAVAL ELECTRONICS SYSTEMS COMMAND

Approved: 15 MAY 1969

LIST OF EFFECTIVE PAGES

PAGE	CHANGE IN	PAGE	CHANGE IN
NUMBERS	EFFECT	NUMBERS	EFFECT
Title Page	Original	3-4 Blank	Original
ii to iv	Original	4-1 to 4-5	Original
1-0 to 1-2	Original	4-6 Blank	Original
2-1 to 2-2	Original	5-1 to 5-6	Original
3-1 to 3-3	Original	6-1 to 6-8	Original

Probescope Co. Inc., 211 Robins Lane, Syosset, New York 11791 Contracts: NOBsr-95398, N00024-67-C-1372

Errors found in this publication (other than obvious typographical errors), which have not been corrected by means of Temporary Corrections or Permanent Changes should be reported. Such report should include the complete title of the publication and the publication number (short title); identify the page and line or figure and location of the error; and be forwarded to the Electronics Publications Section of the Bureau of Ships.

All Navy requests for NAVSHIPS electronics publications listed in the current issue of NAVSANDA Publication 2002 "Requisitioning Guide and Index of Forms and Publications", Cognizance Symbol I, or in a subsequent issue of the Electronics Information Bulletin should be directed to the appropriate Forms and Publications Supply Point.

TABLE OF CONTENTS

Paragra _l	ph	Page	Paragrap	oh.	Page
SE	ECTION 1 - GENERAL INFORMATION	•	S	ECTION 4 - TROUBLESHOOTING	
1-1. 1-2. 1-3. 1-4. 1-5.	Scope	. 1-1 . 1-1 . 1-1	4-1. 4-2.	Troubleshooting . Functional Description a. Attenuator-Mixer b. I-F Amplifier c. Local Oscillator d. Power Supply . Servicing Block Diagram	4-2 4-2 4-2 4-2 4-2
	SECTION 2 - INSTALLATION			SECTION 5 - MAINTENANCE	
2-1. 2-2. 2-3. 2-4. 2-5. 3-1. 3-2. 3-3.	Unpacking and Handling	2-1 2-1 2-1 2-1 3-1 3-1	5-1. 5-2.	Failure, and Performance and Operational Reports Preventive Maintenance a. Maintenance Standards (1) Test Equipment and Special Tools (2) Special Procedures (3) Reference Standards Procedures (4) Preventive Maintenance	5-1 5-1 5-1 5-1 5-1
o-o.	a. Description of Controls	3-1 3-1 3-2 3-2 3-2 3-2		b. Tuning and Adjustment (1) I-F Amplifier Alignment	5-2 5-2
3-4.	Summary of Operating Procedures a. Initial Connections b. Power Off Mode Operation c. Standby Mode Operation d. Operating Mode Operation	3-2 3-2 3-2 3-2 3-2	5-3. 5-4.	(3) Attenuator-Mixer Adjustment	5-2 5-4
3-5.	Operator's Maintenance	3-3 3-3 3-3 3-3	6-1. 6-2. 6-3.	Introduction	6-1
Figure	LIST	OF ILL Page	USTRATIO Figure	NS	Page
J	EGENON 1 GENERAL INFORMATION			Miner Character Characters	1 age
1-1.	ECTION 1 - GENERAL INFORMATION Electronic Frequency Converter CV-2353/U		4-3. 4-4.	Mixer Circuit, Simplified Schematic Diagram Local Oscillator, Simplified	
	SECTION 2 - INSTALLATION		4-5.	Schematic Diagram Power Supply, Simplified Schematic Diagram	
2-1.	Electronic Frequency Converter CV-2353/U Outline Drawing	2-2	4-6.	Servicing Block Diagram	4-5
3-1.	SECTION 3 - OPERATION Front Panel	3-1	5-1.	SECTION 5 - MAINTENANCE Floatronic Fraguency Convertor	
	SECTION 4 - TROUBLESHOOTING		5-1. 5-2.	Electronic Frequency Converter, Overall Schematic Diagram Electronic Frequency Converter, Pottom View	
4-1. 4-2.	Overall Functional Block Diagram Input Circuit, Simplified Schematic Diagram	4-3 4-3	5-3.	Bottom View	

LIST OF TABLES

Γable		Page	Table		Page
	SECTION 1 - GENERAL INFORMATIO	N		SECTION 5 - MAINTENANCE	
1-2.	Signal Characteristics Equipment Supplied Equipment Required But			Reference Standards Procedures Preventive Maintenance	
1-5.	Not Supplied	1-2		Procedures	5-1
	SECTION 4 - TROUBLESHOOTING			SECTION 6 - PARTS LIST	
4-1.	Troubleshooting Chart	4-1		Maintenance Parts List List of Manufacturers	

iv ORIGINAL




Figure 1-1. Electronic Frequency Converter CV-2353/U

GENERAL INFORMATION

1-1. SCOPE.

This Technical Manual is in effect upon receipt. It does not supersede any other publications. Extracts from this publication may be made to facilitate the preparation of other Department of Defense publications.

1-2. GENERAL DESCRIPTION.

The Electronic Frequency Converter CV-2353/U (figure 1-1) is a range extending device that mixes test signals between 100 cps and 2 megacycles with an externally supplied oscillator signal to develop a 2.5-megacycle output signal. The output signal is applied to a radio frequency, single-sideband spectrum analyzer where the power components of the test signal can be analyzed. The converter also contains a 3-megacycle oscillator that is used by the spectrum analyzer.

1-3. REFERENCE DATA.

a. Table 1-1 lists the characteristics of the input and output signals of the converter.

- b. The converter is designed to operate with a spectrum analyzer whose i-f frequency is 500 kilocycles.
- c. The converter operates on 115-volt, single phase, 50, 60 or 400 cycle power.

1-4. EQUIPMENT SUPPLIED.

Table 1-2 lists the equipment supplied with the converter.

1-5. EQUIPMENT REQUIRED BUT NOT SUPPLIED.

Table 1-3 lists the equipment required but not supplied.

1-6. PREPARATION FOR RESHIPMENT.

No extraordinary precautions are required to prepare the converter for reshipment.

TABLE 1-1. SIGNAL CHARACTERISTICS

	FREQ RANGE	VOLTAGE (IN VOLTS)	IMPEDANCE (IN OHMS)	CONNECTOR
INPUT TEST SIGNAL	100 cps to 2 megacycles	0.01 to 3	600 ± 10% Balanced	J101 and J102
			600 ± 10% Unbalanced	J101 and J103
			75 Unbalanced	J103 and J104
EXTERNAL OSCILLATOR	2.5 to 4.5 megacycles	0.1 to 0.3 rms	50	J403
OUTPUT SIGNAL	2.5 megacycles	0.01 at min attenuation	50	Ј203
LOCAL OSCILLATOR	2.985 to 3 megacycles	$0.3 \pm 15\% \ \mathrm{rms}$	50	J107

TABLE 1-2. EQUIPMENT SUPPLIED

	NOMENO	LATURE OVERALL DIMENSIONS (IN)			VOLUME	WEIGHT	
QTY	NAME	DESIGNATION	HEIGHT	WIDTH	DEPTH	(CU FT)	(LB)
1	Converter, Frequency Electronic	CV-2353/U	5-15/64	19	12-15/32	0.72	16
1	Combination Case	E1184	7-1/8	20-1/8	14-3/4	1.2	12
3	Coaxial Cable			72 1	ong	-	0, 22
1	Power Cable	CA301		96 long		-	0.56
1	Tuning Wand	MPI (C2734-2)		6 10	ong	-	0.03
2	Technical Manual for Converter, Frequency, Electronic	CV-2353/U	11	8. 5	3/8	-	-

TABLE 1-3. EQUIPMENT REQUIRED BUT NOT SUPPLIED

QTY	DESCRIPTION	SUGGESTED MODEL OR EQUIVALENT	REQUIRED USE
1	VTVM	Hewlett Packard 400 D	To measure signal amplitudes.
1	Frequency Counter	Hewlett Packard HP5244L	Troubleshooting and alignment.
1	Multimeter	50,000 ohms/volt input resistance with a lower range of 1 volt full scale.	Voltage and resistance checks.
1	Oscilloscope	Tektronix 543 with Type B plug-in.	Troubleshooting local oscillator.
1	50 ohm resistive terminations with BNC connector.	-	Troubleshooting and alignment.

INSTALLATION

2-1. UNPACKING AND HANDLING.

No special precautions are required for the unpacking and handling of the converter. Standard procedures and techniques are adequate.

2-2. POWER REQUIREMENTS.

The converter operates from a 115-volt $\pm 10\%$, 50/60/400 cycle, single phase power source. Power consumption is 40 watts.

2-3. SITE SELECTION. (Fig. 2-1.)

The converter can be placed in any suitable working area with normal lighting and ventilation. It is designed for mounting in a standard 19-inch relay rack. In selecting a site, consideration should be given to the fact that the converter does not operate independently, but operates in conjunction with a spectrum analyzer, an oscillator, and a source of test signals. Therefore, arrangement of all of the units should be considered to achieve the optimum configuration. Because the cables supplied are 6-feet long, the converter should be situated so that the cables will conveniently reach the associated equipment.

2-4. CABLE ASSEMBLIES.

a. The equipment is supplied with four cables (table 1-2). The three coaxial cables are each 6 feet long. They are used to connect signals from the converter to the spectrum analyzer and the external variable frequency oscillator. All three cables are identical and may be used interchangeably.

b. The 8-foot power cable is connected between the POWER jack (14, figure 3-1) and a source of 115-volt, 50/60/400 cycle, single-phase power.

2-5. INSPECTION AND ADJUSTMENT.

- a. Check the fuse and mechanical operation of controls (figure 3-1). Failure of any control to operate properly is sufficient cause for failure of the converter to pass this test.
- (1) Remove the caps from the fuseholders and check that both fuses are rated at 1/4 ampere. Visually inspect the fuses for any defects. Replace the fuses and caps.
- (2) Operate the CENTER FREQUENCY KC control over its entire range. It should move smoothly without binding or sticking.
- (3) Operate all switches to all positions. Switches should operate smoothly and seat positively in each position.
- (4) Check that all internal cables are securely connected.
- b. Check the electrical operation of the converter as follows:
- (1) Connect the power cable between the POWER jack and source of the 115-volt 50/60/400 cycle power.
- (2) Place the POWER switch in the STANDBY position. The power-on indicator should light to indicate that the converter is energized.




Figure 2-1. Electronic Frequency Converter CV-2353/U Outline Drawing

OPERATION

3-1. FUNCTIONAL OPERATION.

- a. The converter mixes a test signal between 100 cps and 2 megacycles with an external oscillator signal to develop a 2.5 megacycle signal. The resultant signal is applied to a spectrum analyzer where power as a function of frequency can be analyzed. In addition, the converter contains an oscillator that generates a 3-megacycle signal also applied to the spectrum analyzer.
- b. In the operate mode, the converter handles test signals in the 100 cps to 2 mc range. In the standby mode, the converter routes external oscillator signals up to 40 mc to the spectrum analyzer without mixing.

3-2. PREPARATION FOR USE.

After the converter is installed, check the electrical operation by proceeding as described in paragraph 2-5b.

3-3. OPERATING PROCEDURES.

a. DESCRIPTION OF CONTROLS. The operating controls and indicators are listed below and illustrated in figure 3-1.

- (1) 1/4 A. SB fuse 2F301 (1, figure 3-1) protects input power line in the event of a converter short circuit.
- (2) Power on indicator, 05301 (2) indicates that a-c power has been applied.
- (3) EXT OSC. INPUT jack, J107 (3) input jack for the external oscillator signal.
- (4) CENTER FREQUENCY KC control, R404 (4) varies the internal oscillator between 2985 kc and 3000 kc.
- (5) INPUT ATTENUATOR DB switches, S101, S102, and S103 (5) adjusts the amplitude of the input test signal.
- (6) SIGNAL INPUT-75 Ω jack J104 (6) input jack for test signal.
- (7) SIGNAL INPUT $600\,\Omega$ jacks, J101 and J102 (7) the jacks to which a balanced 600-ohm impedance input test signal is connected.
- (8) SIGNAL INPUT-GND jack, J103 (8) ground connections for 75-ohm and 600-ohm unbalanced input, test signals.




Figure 3-1. Front Panel

- (9) SIGNAL INPUT switch, S104 (9) establishes internal circuit to accept either 75-ohm or 600-ohm impedance input.
- (10) OUTPUT jack, J203 (10) jack at which test signal output is available.
- (11) INTERNAL OSC. OUTPUT jack, J403 (11) jack at which internal oscillator or switched external oscillator signal output is available.
- (12) BALANCE control, R127 (12) controls oscillator leakage signal amplitude at mixer output.
- (13) POWER switch, S301 (13) establishes mode of operation.
- (14) POWER jack, J303 (14) jack to which a-c power cable is connected.
 - (15) 1/4 A. SB fuse, F302 (15) line fuse.
 - b. SEQUENCE OF OPERATION.
- (1) BEFORE USE. Before using the converter, proceed as follows:
- (a) The spectrum analyzer that is to be used with the converter must develop a 500 kc i-f signal. Check by applying signals to the SIGNAL INPUT and EXT OSC INPUT jacks that differ by 500 kc. Observe the spectrum analyzer screen. The amplitude of the oscillator input signal should be 0.3-volt rms.
- (b) Make the connections described in paragraph 3-4a.
- (c) Place the POWER switch in the STANDBY position. The power-on indicator should light.
- (2) DURING USE. Except for the front panel power-on indicator, there are no other indicators that require frequent monitoring.
- (3) AFTER USE. Although the converter is transistorized, it is recommended that the POWER switch remain in the STANDBY position if the unit is going to be used intermittently. If it will not be used for a long time, place the POWER switch in the OFF position.

3-4. SUMMARY OF OPERATING PROCEDURES.

- a. INITIAL CONNECTIONS. To connect the converter to the spectrum analyzer and the external oscillator, proceed as follows:
- (1) Connect a coaxial cable between the EXT OSC INPUT jack (3, figure 3-1) and the output of a variable frequency generator or signal generator.
- (2) Connect a coaxial cable between the INTERNAL OSC. OUTPUT jack (11) and the oscillator input of the spectrum analyzer.

- (3) Connect a coaxial cable between the OUTPUT jack (10) and the spectrum analyzer signal input.
- (4) Connect the input test signal to the SIGNAL INPUT jacks. Select the proper jacks as follows:
- (a) If the test signal impedance is 600-ohms balanced to ground, connect the signal between the SIGNAL INPUT-600 Ω jacks (10). Place the SIGNAL INPUT switch (9) in the 600 Ω position.
- (b) If the test signal impedance is 600-ohms unbalanced, connect a jumper between either of the SIGNAL INPUT-600 Ω jacks (10) and the SIGNAL INPUT-GND jack (8). Connect the signal between the ungrounded and the grounded SIGNAL INPUT-600 Ω jacks. Place the SIGNAL INPUT switch (9) in the 600 Ω position.
- (c) If the test signal impedance is 75 ohms, connect the signal to the SIGNAL INPUT-75 Ω jack (6). Place the SIGNAL INPUT switch (9) in the 75 Ω position.
- (5) Connect the power cable to the POWER jack (14).
- b. POWER OFF MODE OPERATION. If it is desired to operate in the frequency range of 2 to 40 mc, place the POWER switch (13, figure 3-1) in the OFF position. The external oscillator signal is routed directly to the spectrum analyzer via INTERNAL OSC. OUTPUT jack (11). No further operation of the converter is required.
- c. STANDBY MODE OPERATION. If it is desired to operate intermittently in the 100 cps to 2 mc range, place the POWER switch (13) in the STANDBY position. The POWER ON indicator (2) will light. Signal routing is the same as for power off mode (paragraph 3-4b, above). In addition, the internal oscillator is energized and ready for use.
- d. OPERATING MODE OPERATION. To operate with signal frequencies in the 100 cps to 2 mc range, proceed as follows:
- (1) Adjust the INPUT ATTENUATOR DB switches (5, figure 3-1) for maximum attenuation.
- (2) Place the POWER switch (13) in the OPERATE position. The power on indicator (2) will light.

NOTE

The operation of the converter is intimately associated with the operation of a spectrum analyzer and external variable frequency oscillator. Because the converter can operate with various analyzers and oscillators, the operating procedure described in this manual can only be of a general nature. Refer to the applicable spectrum analyzer and variable frequency oscillator manuals to determine the specific operating procedures required.

- (3) Set the frequency of the external oscillator so that it is 2.5 megacycles higher than the test signal.
- (4) Adjust INPUT ATTENUATOR DB switches (5) until the desired amplitude signal is obtained.
- (5) The carrier frequency should now be displayed in the center of spectrum analyzer scope display. If not, adjust the CENTER FREQUENCY KC control (4) and the external oscillator frequency until the carrier frequency display is properly positioned. For test signal frequencies higher than the maximum sweep width of the analyzer, the carrier frequency displayed when either of the sidebands is displayed.
- (6) The carrier frequency amplitude should be less than the amplitude of the sidebands when a 10 millivolt rms input signal is displayed. If not,

use a screwdriver to adjust the BALANCE control (12) for minimum carrier amplitude.

3-5. OPERATOR'S MAINTENANCE.

- a. OPERATING CHECKS. The converter does not require checking during operation.
- b. PREVENTIVE MAINTENANCE. Preventive maintenance is described in Section 5.
- c. EMERGENCY MAINTENANCE. The only maintenance authorized for the operator is to check and replace 1/4 A. SB fuses (1 and 15, figure 3-1). They should be checked only if the power on indicator (2) does not light when power is applied.

CAUTION

If the new fuses burn out, do not replace them. Refer to Section 4, Troubleshooting.

TROUBLESHOOTING

4-1. TROUBLESHOOTING.

This section describes the troubleshooting techniques for the converter. The information consists of a logic troubleshooting procedure in tabular form, a servicing block diagram, and the theory of operation. Converter malfunction will appear as no signal displayed on the spectrum analyzer with which the converter is operating. When troubleshooting the

equipment, refer to table 4-1 and the following illustrations:

- a. Figure 3-1. location of front panel controls.
- b. Figure 4-6. block diagram showing interconnection of sections and voltages to be measured at critical points.
 - c. Figure 5-1. overall schematic diagram.

TABLE 4-1. TROUBLESHOOTING CHART

STEP	SYMPTOM	PROBABLE CAUSE	REMEDY
1	Power on indicator does not light when POWER switch is in the STANDBY OR OPERATE position.	a. Defective fuse.	a. Replace fuse if defective. CAUTION
			Do not replace with a fuse rated higher than 1/4 ampere. If fuse burns out again, do not replace until trouble has been located. Disconnect power and check for short circuit.
		b. Defective lamp.	b. Replace lamp if defective.
		c. A-c power not applied.	c. Check power, source, power cable, and POWER switch \$301.
2	Absence of -15 volts dc at test point TP301.	Defective power supply.	Perform voltage and resistance checks to locate defective circuit element on power supply.
3	A signal between 2985 kc and 3000 kc is not observed	a. Detuned oscillator.	a. Adjust per paragraph 5-2b(2).
	on frequency counter connected to INTERNAL OSC. OUTPUT jack J403.	b. Defective oscillator.	 Perform voltage and resistance checks to locate defective circuit elements. Adjust per para- graph 5-2b(2).
		c. POWER switch S301 defective.	c. Replace S301 if defective.
4	With external oscillator and test signals connected, no signal is observed on an	a. Defective diodes in balanced mixer.	 Replace CR101 through CR104 if defective.
	oscilloscope connected to jack J105, regardless of the position of the INPUT ATTENUATOR DB switches.	b. Defective circuit elements in balanced mixer.	b. Perform resistance checks to locate defective element.

TABLE 4-1. TROUBLESHOOTING CHART (Cont)

STEP	SYMPTOM	PROBABLE CAUSE	REMEDY
5	With same connections as in step 4, output is observed for only some settings of the INPUT ATTENUATOR DB switches.	Defective resistor or switch.	Perform resistance checks to determine defective circuit element.
6	With a test and external oscillator signal applied, no output is observed on the VTVM connected to the OUTPUT jack. NOTE A 50-ohm resistive load must be connected between the OUTPUT jack and ground before the measurement is made.	a. Detuned i-f amplifier.b. Defective i-f amplifier.	 a. Adjust the amplifier as per paragraph 5-2b(1). b. Perform voltage and resistance checks to determine defective circuit element.

4-2. FUNCTIONAL DESCRIPTION.

The converter consists of four sections; an Attenuator-Mixer, an I-f Amplifier, a Local Oscillator, and a Power Supply (figure 4-1). Figure 5-1 is an overall schematic diagram showing all four sections. Refer to this figure for detailed circuit analysis and troubleshooting information. The following functional description uses simplified diagrams to clarify the discussion.

- a. ATTENUATOR-MIXER. The 600-ohm test-signal input, either balanced or unbalanced, is applied to the attenuator (figure 4-2). Effectively the attenuator is a variable resistor that establishes the desired input-signal, voltage level. The setting of INPUT ATTENUATOR switches S101, S102 and S103 determines the circuit resistance, hence the attenuation. The attenuator output is developed across resistor R124.
- (1) The 75-ohm test-signal input is connected across an impedance-matching circuit consisting of R125 and 126. The output of this circuit is then applied to the attenuator. The operation of the attenuator is identical to that described in paragraph 4.2a, above.
- (2) The test-signal input is mixed with the external oscillator signal as shown in figure 4-3. The test signal, developed across resistor R124, (paragraph 4-2a (1)), modulates the external oscillator signal developed at the input of T101. The BALANCE control, R127, adjusts the amplitude of the test signal. The modulation causes beat frequencies to be developed in output transformer T102. The external oscillator frequency is adjusted so that one of the beat frequencies will be 2.5 megacycles.

- b. I-F AMPLIFIER. The i-f amplifier consists of three identical stages. The output of the mixer is R-C coupled to the i-f amplifier. The 2.5-megacycle beat frequency is amplified while all other input frequencies are suppressed. The 2.5-megacycle output frequency is developed between OUTPUT jack J203 and ground.
- c. LOCAL OSCILLATOR. The local oscillator, figure 4-4, is a modified Hartley, called a Colpitts oscillator. The frequency of oscillation is controlled by voltage divider R404, R407, R414 and voltage-controlled capacitor CR401.
- (1) The adjustment of CENTER FRE-QUENCY control R404 determines the voltage across CR401. This, in turn, determines the capacitance of CR401. Because CR401 is in parallel with the oscillator tank circuit, its capacitance will affect the frequency at which the tank circuit oscillates. In summary, adjusting CENTER FREQUENCY control R404 changes the voltage across CR101, which changes its capacitance causing a shift in oscillator frequency. The oscillator frequency can be adjusted between 2985 kc and 3000 kc.
- (2) The oscillator output is applied through capacitor C403 and two emitter followers (Q402 and Q403) to INTERNAL OSC. OUTPUT jack J403. Zener diode CR403 maintains a constant voltage at the collector of Q403. Hence it stabilizes the output voltage.
- d. POWER SUPPLY. The full-wave rectifier in the power supply (figure 4-5) develops -45 volts dc at the collector of control transistor Q301. Zener diode CR301 maintains the base of Q301 at a constant -30 volts dc regardless of fluctuations in the

input ac voltage. Zener diode CR302 maintains the base of transistor Q302 at a constant -16 volts dc. Thus, with the collector and base voltages of Q302 held constant, the voltage across the emitter of Q302 is a constant -15 volts dc. This is the B- supply output for the I-f Amplifier and Local Oscillator.

jacks are assigned star test point symbols. These are used to isolate functional sections when trouble-shooting. Along with the star test point symbols, the diagram indicates the proper voltage and frequency at each jack.

4-3. SERVICING BLOCK DIAGRAM.

Figure 4-6 is a servicing block diagram that acts as a guide during troubleshooting. Several




Figure 4-1. Overall Functional Block Diagram




Figure 4-2. Input Circuit, Simplified Schematic Diagram




Figure 4-3. Mixer Circuit, Simplified Schematic Diagram




Figure 4-4. Local Oscillator, Simplified Schematic Diagram




Figure 4-5. Power Supply, Simplified Schematic Diagram




Figure 4-6. Servicing Block Diagram

MAINTENANCE

5-1. FAILURE, AND PERFORMANCE AND OPERATIONAL REPORTS.

The Bureau of Ships no longer requires the submission of failure reports for all equipments. Failure Reports and Performance and Operational Reports are to be accomplished for designated equipments (refer to Electronics Installation and Maintenance Book, NAVSHIPS 900, 000) only to the extent required by existing directives. All failures shall be reported for those equipments requiring the use of Failure Reports.

5-2. PREVENTIVE MAINTENANCE.

a. MAINTENANCE STANDARDS.

(1) TEST EQUIPMENT AND SPECIAL TOOLS. - The test equipment required to perform preventive maintenance is listed in table 1-3.

- (2) SPECIAL PROCEDURES. There are no special procedures required before performing the preventive maintenance procedures.
- (3) REFERENCE STANDARDS PRO-CEDURES. - Table 5-1 lists the reference standards that assure proper operation of the converter.
- (4) PREVENTIVE MAINTENANCE PROCEDURES. Perform the tests described in table 5-2 every 6 months.

NOTE

The procedures listed below consist of the minimum number of reference standards which will indicate, when completed, the relative performance of the converter. The procedures are listed in the suggested sequence of performance; however, deviation from the listed order will in no way affect the unit or result of the reference standard.

TABLE 5-1. REFERENCE STANDARDS PROCEDURES

SECTION	ACTION REQUIRED	REFERENCE
I-f Amplifier	Measure output voltage at J203.	Para. 5-2.b.(1)
Oscillator	Measure output voltage at J403.	Para. 5-2.6.(2)
Power Supply	Measure voltage at TP301.	Table 4-1, Step 2

TABLE 5-2. PREVENTIVE MAINTENANCE PROCEDURES

WHAT TO CHECK	HOW TO CHECK	CORRECT RESULTS
Controls	Operate all controls through all positions.	Smooth, positive action
Chassis	Remove dust and dirt with clean, lintless cloth or brush.	
Mechanical	Tighten all loose screws. Check for chipped, scratched or peeling paint.	
Visual	Check for discolored or cracked resistors and capacitors.	
Gain	Set the input test signal for 100 kc, 10 mv amplitude. Operate the equipment as described in paragraph 3-4 with the INPUT ATTENUATOR DB switches set for zero attenuation.	The amplitude of the center frequency displayed on the spectrum analyzer should be approximately 10 mv.

- b. TUNING AND ADJUSTMENT. The following tuning and adjustment procedure should be performed whenever a circuit element or entire section is replaced. The following procedures are independent of each other and may be performed in any order.
- (1) I-F AMPLIFIER ALIGNMENT. To perform the following procedure, the technician requires a VTVM, a 50-ohm resistive termination, and the tuning wand supplied with the equipment.
- (a) Connect a 50-ohm resistive termination between OUTPUT jack J203 and ground.
- (b) Connect a VTVM between the OUTPUT jack and ground,
- (c) Connect a 100 kc, 10 mv rms test signal to the proper SIGNAL INPUT jacks (paragraph 3-4a(4)).
- (d) Connect a 2.6 mc external oscillator signal to the EXT OSC. INPUT jack.
- (e) Place the INPUT ATTENUATOR DB switches in the 0 position.
- (f) Place the POWER switch in the OPERATE position.
- (g) Adjust inductor L203 for a maximum indication on the VTVM.

NOTE

If adjustment of inductor L203 causes the output voltage to exceed 10 mv rms, adjust the INPUT ATTENUATOR DB switches so that the output voltage is 10 mv or less.

- (h) Repeat step (g) for inductor L202.
- (i) Repeat step (g) for inductor L201.
- (j) Repeat steps (g), (h), and (i) in that sequence until either a maximum output voltage or 10 my rms is obtained.
- (2) INTERNAL OSCILLATOR ALIGNMENT.

 To perform the following procedure, the technician requires a frequency counter and a 50-ohm resistive termination.
- (a) Connect the 50-ohm resistive termination and the frequency counter between the INTERNAL OSC. OUTPUT jack and ground.
- (b) Place the POWER switch in the OPERATE position.


- (c) Set the CENTER FREQUENCY KC control to the 0 position.
- (d) Adjust inductor L401 until the frequency counter indicates 3000 kc.
- (e) Set the CENTER FREQUENCY KC control to the 15 position.
- (f) Adjust lower frequency limit control R407 until the frequency counter indicates 2985 kc.
- (g) Repeat steps (c) through (f) until both limit frequencies are correct.
- (3) ATTENUATOR-MIXER ADJUST-MENT. To perform the following procedure, the technician requires a jumper wire and a test signal source.
- (a) Connect a jumper between SIGNAL INPUT jacks J102 and J103.
- (b) Set the INPUT ATTENUATOR DB switches for 40 db attenuation.
- (c) Connect a test signal to SIGNAL INPUT jacks J101 and J103. The test signal frequency should be 2 mc; and the amplitude should be 1 volt rms.
- (d) Operate the converter as described in paragraph 3-4.
- (e) Note the amplitude of the sideband frequency displayed on the spectrum analyzer.
- (f) Increase the amplitude of the input signal by 5 db (to approximately 1.78 volts rms).
- (g) The amplitude of the sideband frequency displayed on the spectrum analyzer should increase by 5 db.
- (h) Adjust the INPUT ATTENUATOR DB switches for 45 db attenuation. The amplitude of the carrier frequency should return to the level noted in step (e).
- (i) If the proper amplitude is not obtained in step (h), adjust capacitor C101 until the proper amplitude is obtained.
- (j) Repeat steps (c) through (i) until the carrier frequency signal amplitude is proper and stable.


PART LOCATION INDEX

. .

C101 16G E12 19F R115 12F C102 16E E13 18F R116 11E C201 23E F301 3D R117 9E C202 25C F302 2D R118 9E C202 25C F302 2D R118 9E C203 26C J101 7C R119 9F C204 26D J102 7D R120 9E C206 28C J103 7E R121 17F C207 29C J104 7D R122 17G C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C2301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C411 26J P204 21E R214 23F C412 19J P303 2C R301 17F P402 18J R401 16J CR101 17F P402 18J R401 15J CR303 9I Q401 21J R407 22J CR303 9J Q402 22K R103 16A R412 22J CR303 9J Q402 24K R408 22J CR303 1J R406 21K CR303 9J Q402 24K R408 22J CR305 10J R406 21K CR303 9J Q401 21J R407 15J CR304 9J Q402 24K R408 22J CR305 10J R406 21K CR303 9J Q401 21J R407 15J CR304 9J Q402 24K R408 22J CR305 10J R406 21K CR303 9J Q401 21J R407 15J CR304 9J Q402 24K R408 22J CR305 10J R406 21K CR303 9J Q401 21J R407 15J CR304 9J Q402 24K R408 22J CR305 10J R406 21K CR303 9J Q401 21J R407 15J CR304 9J Q402 24K R408 22J CR305 10J R406 15B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 15K D5301 5F R105 13B R415 16K E2 7J R107 13B S102 12C E3 31 12I R108 13B S103 10F E5 14I R110 10A S301 SE, F, H, I, K, L E6 14I R111 10B T101 15F E5 14I R110 10A S301 SE, F, H, I, K, L E6 14I R111 10B T101 15F E5 14I R114 12E T3301 8L E11 18F R114 12E T3301 8L	REF DESIG	LOC	REF DESIG	LOC	REF DESIG	LOC	
C102 16E E13 18F R116 11E C201 23E F301 3D R117 9E C202 25C F302 2D R118 9E C203 26C J101 7C R119 9F C204 26D J102 7D R120 9E C206 28C J103 7E R121 17F C207 29C J104 7D R122 17G C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C211 32D J202 33D R127 18F C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR304 9J Q402 24I R408 22I CR305 10 Q403 25J R406 22J CR305 10 Q403 25J R408 22J CR305 10 Q403 25J R406 22J CR305 10 Q405 24I R408 22J CR305 10 Q405 24I R408 22J CR305 10 Q405 24F CR405 25Z CR305 10 G406 15G CR406 15G CR407 17J R106 13A S101 15F E8 22A R	DESIG	LOC	DESIG	HOC	DEDIG		
C201 23E F301 3D R117 9E C202 25C F302 2D R118 9E C203 26C J101 7C R119 9F C204 26D J102 7D R120 9E C206 28C J103 7E R121 17F C207 29C J104 7D R122 17G C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C212 32D J202 33D R127 18F C301 111 J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 C R302 11J CR101 17F P402 18J R401 16J CR101 17F P402 18J R401 16J CR101 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR303 9I Q401 21J R407 15J CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR306 10J R101 15B R410 23J CR307 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 71 R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R108 13B S103 10F E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I	C101	16G					
C202 25C F302 2D R118 9E C203 26C J101 7C R119 9F C204 26D J102 7D R120 9E C206 28C J103 7E R121 17F C207 29C J104 7D R122 17G C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 111 J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR103 18G Q202 27E R403 20J CR303 9I Q401 21J R405 CR304 15F R105 13B R410 16J CR305 10J R406 25K CR403 25J R107 15B R410 23J CR306 10J R101 15B R410 23J CR307 17J R107 15B R410 16J CR308 11J R309 27E R408 22I CR309 1 Q401 21J R407 15J CR301 117 R408 25J R409 23J CR303 15F R103 16A R412 25K CR403 25J R104 16B R411 24K CR401 17J R101 15B R410 23J CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR306 10J R101 15B R410 23J CR307 17J R107 13B S102 12C E3 12I R108 13B S103 10F E4 121 R108 13B S103 10F E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I	C102	16E					
C203 26C J101 7C R119 9F C204 26D J102 7D R120 9E C206 28C J103 7E R121 17F C207 29C J104 7D R122 17G C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 11I J204 22E R201 23D C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C401 18K J403 1K R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R206 2	C201	23E					
C204 26D J102 7D R120 9E C206 28C J103 7E R121 17F C207 29C J104 7D R122 17G C207 29C J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K L201 24D R206 27F C402 18K L201 24D R206 27F C402 18K L201 24D R209 <td< td=""><td>C202</td><td>25C</td><td></td><td></td><td></td><td></td><td></td></td<>	C202	25C					
C206 28C J103 7E R121 17F C207 29C J104 7D R122 17G C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q402 24I R408 22I CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR306 10J R101 15B R410 23J CR307 25K R105 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 124K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 124K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 124K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 15K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 124K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 124K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 124K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 15F CR306 10J R101 15B R410 23J CR307 17J R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R108 13B S103 10F E4 12I R108 13B S103 10F E5 14I R111 10B T101 15F E6 14I R111 10B T101 15F E6 14I R111 10B T101 15F E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I	C203	26C					
C207 29C J104 7D R122 17G C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 111 J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210	C204						
C208 29D J105 19E R124 14F C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C406 16K L401 19J R209							
C210 31C J106 15G R125 15D C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR403 25J R105 13B R401 165 CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR403 25J R105 13B R404 15K CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR403 25J R105 13B R404 15K CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR307 17I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E8 22A R113 12E T301 8I	C207						
C211 32C J107 1G R126 15E C212 32D J202 33D R127 18F C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR307 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR403 25J R104 16B R411 15K DS301 5F R105 13B R415 16K E1 71 R106 13A S101 16C E2 7J R107 13B S102 12C CR301 12I R108 13B S103 10F E4 12I R108 13B S103 10F E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F							
C212 32D J202 33D R127 18F C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR307 P408 P409 P508 P609 P609 P609 P609 P609 P609 P609 P609							
C301 11I J204 22E R201 23D C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR101 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
C302 10K J303 2D R202 23F C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR306 10J R101 15B R410 23J CR307 25K R105 13B R415 16K CR401 25J R104 16B R411 25K CR403 25J R104 16B R411 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 15A S10 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E8 22A R113 12E T301 8I							
C303 7K J402 25L R203 24F C401 18K J403 1K R204 25B C402 18K L201 24D R206 27C C403 18J L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
C401 18K							
C402 18K							
C402 16K L202 28D R207 27F C404 19J L203 31D R208 29B C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR403 25J R104 16B R411 15K DS301 5F R105 13B R415 16K E1 71 R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
C403 1806							
C406 16K L401 19J R209 27F C407 17J L403 15I R210 30C C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R411 24K CR403 25J R104 16B R411 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E66 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
C400 101							
C408 22J P105 20E R211 30F C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407							
C409 25K P106 15G R212 32B C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR101 17F P402 18J R401 16J CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409							
C410 16I P202 34D R213 31F C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409							
C411 26J P204 21E R214 23F C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412							
C412 19J P303 2C R301 9K C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>							
C413 19K P304 2C R302 11J CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>							
CR101 17F P402 18J R401 16J CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
CR102 17F Q201 24E R402 20I CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
CR103 18G Q202 27E R403 20J CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
CR104 18F Q203 31E R404 15J CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103							
CR301 11J Q301 10I R405 22I CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>							
CR302 9J Q302 8J R406 21K CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
CR303 9I Q401 21J R407 15J CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							
CR304 9J Q402 24I R408 22I CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102							
CR305 10I Q403 25J R409 23J CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301							
CR306 10J R101 15B R410 23J CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I						23J	
CR401 17J R102 16B R411 24K CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I					R410	23J	
CR402 22K R103 16A R412 25K CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I					R411	24K	
CR403 25J R104 16B R414 15K DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I				16A	R412	25K	
DS301 5F R105 13B R415 16K E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I		25J	R104	16B			
E1 7I R106 13A S101 16C E2 7J R107 13B S102 12C E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I			R105	13B	R415	16K	
E3 12I R108 13B S103 10F E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I			R106	13A	S101		
E4 12I R109 10B S104 16E E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I	$\mathbf{E2}$	7J	R107	13B			
E5 14I R110 10A S301 3E, F, H, I, K, L E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I	E3	12I	R108	13B			
E6 14I R111 10B T101 15F E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I	E4	121					
E7 22B R112 11B T102 17E E8 22A R113 12E T301 8I							F, H, I, K, L
E8 22A R113 12E T301 8I							
E11 18F R114 12E TP301 7L							
	E11	18F	R114	12E	TP301	TLi	

```
3
                                                                                                                     6
                                                                                                                               ATTENUATOR MIX
NDEX
         REF
         DESIG
                    LOC
         R115
                     12F
                                                                      P304
115V AC ±10%
50-400℃
         R116
                     11E
         R117
                    9E
                                                                        POWER
         R118
                    9E
         R119
                    9F
                    9E
         R120
         R121
                     17F
                     17G
         R122
                                                                                                                                JIOI
                                                                                                                      e00V
                                                                 P303
                     14F
         R124
                                                                                                                                J104
         R125
                     15D
                                                                                                                      75 A
         R126
                    15E
                                                                  J303
                                                                                                            SIGNAL
         R127
                     18F
                                                                                                                                J102
                                                                                                                      600V
                                                                F302
         R201
                     23D
                                                                                   F 301
                                                             1/4 A SB
                                                                                 1/4 A SB
         R202
                     23F
                                                                                 12 OFF
                                                                                                                                 J103
                                                                                                                       GND
         R203
                     24F
         R204
                     25B
                                                                                    STANDBY
                                               Ε
         R206
                     27C
                                                    S30I
POWER
         R207
                    27F
         R208
                    29B
                                                                                   OPERATE
                                                                                                     DS 301
         R209
                    27F
                                                                                  06
                    30C
         R210
         R211
                    30F
         R212
                    32B
         R213
                    31F
         R214
                    23F
         R301
                    9K
         R302
                    11J
                                                                                  012
         R401
                    16J
                                                          J107
                                                                                   011
         R402
                                                        EXT. OSC.
                    20I
         R403
                    20J
         R404
                    15J
                                                                                                                              POWER SUPPLY
         R405
                    221
         R406
                    21K
         R407
                    15J
         R408
                    22I
         R409
                    23J
         R410
                    23J
                                                                                                                                     II5V
RMS
         R411
                    24K
         R412
                    25K
                                                                                                                               E2°
         R414
                    15K
                                                                                                                                     Q302
2N297A
VOLTAGE
REGULATOR
         R415
                    16K
         S101
                    16C
                                                                                  012
         S102
                    12C
                                                            J 403
                                                                                                                                     C303 =
                                                         INTERNAL
         S103
                    10F
                                                          OSC
OUTPUT
         S104
                    16E
         S301
                    3E, F, H, I, K, L
         T101
                    15F
         T102
                    17E
                                                                                  0<u>6</u>
                                                                                                                                 TP301
-15 V DC
         T301
                    81
         TP301
                    71.
```








Figure 5-1. Electronic Frequency Converter, Overall Schematic Diagram

5-3. REPAIR AND REPLACEMENT.

None of the parts of the converter should be repaired. All parts are to be replaced. Standard techniques are adequate. No special procedures are required for assembly, disassembly or replacement. After replacing a defective part, refer to the adjustment procedures in paragraph 5-2b to assure proper operation of the equipment.

5-4. ILLUSTRATIONS.

a. PART LOCATION. - To facilitate the location of parts when replacement is necessary, the following illustrations are provided:

- (1) Front view of operating controls and indicators, figure 3-1.
- (2) Bottom view of Electronic Frequency Converter CV-2353/U, figure 5-2.
- (3) Top view of printed circuit boards, figure 5-3.
- b. OVERALL SCHEMATIC DIAGRAM. Figure 5-1 is an overall schematic diagram of the equipment. The major signal paths are indicated by heavy lines and the direction of signal flow by arrows.




Figure 5-2. Electronic Frequency Converter, Bottom View





Figure 5-3. Printed Circuit Board Parts Location (Sheet 1 of 2)






Figure 5-3. Printed Circuit Board Parts Location (Sheet 2 of 2)

PARTS LIST

6-1. INTRODUCTION.

a. REFERENCE DESIGNATIONS. - The unit numbering method of assigning reference designations have been used to identify units, assemblies, subassemblies and parts. This method has been expanded as much as necessary to adequately cover the various degrees of subdivision of the equipment. Examples of this unit numbering method and typical expansions of the same are illustrated by the following:

Example 1:
$$\frac{1}{\text{Unit No.}}$$
 $\frac{R}{\text{Class of Item}}$ $\frac{101}{\text{Item No.}}$ within class

Read as: First (1) resistor (R) of first unit (101)

b. REFERENCE DESIGNATION PREFIX. Partial reference designations are used on the equipment and illustrations. The partial reference designations consist of the class letter(s) and the identifying item number. Prefixes are provided on illustrations following the notation "REF DESIGN PREFIX."

6-2. MAINTENANCE PARTS LIST.

Table 6-1 lists all units and their maintenance parts. The units are listed in numerical sequence.

Maintenance parts for each unit are listed alphabetically-numerically by class of part following the unit number. Thus the parts for each unit are grouped together. Table 6-1 contains the following information: (1) the complete reference designation of each unit, assembly, subassembly, or part (2) reference to explanatory notes that may be used (3) noun name and brief description, and (4) identification of the illustration which pictorially locates the part.

Printed circuit boards, assembly boards, modules, etc., are listed first as individual items in the maintenance parts list. In addition, at the completion of a parts listing for each unit, the individual circuit board, module, etc., is broken down by components into separate parts listings. When there is a redundancy of such electronic assemblies or parts in subsequent units, reference is made to the parts breakdown or parts previously listed.

6-3. LIST OF MANUFACTURERS.

Table 6-2 lists the manufacturers of parts used in the CV-2353/U Frequency Electronic Converter. The table includes the manufacturer's code used in table 6-2 to identify the manufacturers.

TABLE 6-1. MAINTENANCE PARTS LIST

CONVERTER, FREQUENCY ELECTRONIC, CV-2353/U, A2176

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG.
-		CONVERTER, FREQUENCY, ELECTRONIC: CV-2353/U; 06181 NO. A2176	5-2
1		MIXER, ATTENUATOR: RE-50M; 06181 NO. D2174	5-2
2		AMPLIFIER, IF: 06181 NO. C2127	5-2
3		POWER SUPPLY: 06181 NO. C2122	5-2
4		OSCILLATOR: 06181 NO. C2132	5-2

ATTENUATOR MIXER, D2174

1	MIXER, ATTENUATOR: 06181 NO. D2174	5-2
CR101	SEMICONDUCTOR DEVICE: 81349 NO. 1N277	5-3, SH. 1

TABLE 6-1. MAINTENANCE PARTS LIST (Cont)

ATTENUATOR MIXER, D2174 (Cont)

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG. NO.
CR102		SEMICONDUCTOR DEVICE: SAME AS CR101	5-3, SH. 1
CR103		SEMICONDUCTOR DEVICE: SAME AS CR101	5-3, SH. 1
CR104		SEMICONDUCTOR DEVICE: SAME AS CR101	5-3, SH. 1
C101		CAPACITOR: 81349 NO. CV11D450	5-2
C102		CAPACITOR: 81349 NO. CM15D100J	5-3, SH. 1
E11		TERMINAL, TEFLON: 12615 NO. 29P1071	5-1
E12		TERMINAL, TEFLON: SAME AS E11	5-1
E13		TERMINAL, TEFLON: SAME AS E11 .	5-1
J101		CONNECTOR, BINDING POST: RED; 58470 NO. DF30RC	3-1
J102		CONNECTOR, BINDING POST: SAME AS J101	3-1
J103		CONNECTOR, BINDING POST: BLACK; 58474 NO. DF30BC	3-1
J104		CONNECTOR: 81349 NO. UG1094A/U	3-1
J105		CONNECTOR: 81349 NO. UG909A/U	5-2
J106		CONNECTOR: SAME AS J105	5-2
J107		CONNECTOR: SAME AS J105	3-1
P105		CONNECTOR: 81349 NO. UG88/U	5-2
P106		CONNECTOR: SAME AS P105	5-2
R101		RESISTOR: 81349 NO. RN60B2151F	5-2
R102		RESISTOR: 81349 NO. RN60D1820F	5-2
R103		RESISTOR: SAME AS R102	5-2
R104		RESISTOR: SAME AS R101	5-2
R105		RESISTOR: 81349 NO. RN60B1151F	5-2
R106		RESISTOR: 81349 NO. RN60B4220F	5-2
R107		RESISTOR: SAME AS R106	5-2
R108		RESISTOR: SAME AS R105	5-2
R109		RESISTOR: SAME AS R105	5-2
R110		RESISTOR: SAME AS R106	5-2
R111		RESISTOR: SAME AS R106	5-2
R112		RESISTOR: SAME AS R105	5-2

TABLE 6-1. MAINTENANCE PARTS LIST (Cont)

ATTENUATOR MIXER, D2174 (Cont)

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG. NO.
R113		RESISTOR: 81349 NO. RN60B7320F	5-2
R114		RESISTOR: 81349 NO. RN60B1471F	5-2
R115		RESISTOR: SAME AS R114	5-2
R116		RESISTOR: SAME AS R113	5-2
R117		RESISTOR: SAME AS R105	5-2
R118		RESISTOR: SAME AS R106	5-2
R119		RESISTOR: SAME AS R106	5-2
R120		RESISTOR: SAME AS R105	5-2
R121		RESISTOR: 81349 NO. RC20GF561J	5-3, SH. 1
R122		RESISTOR: SAME AS R121	5-3, SH. 1
R124		RESISTOR: 81349 NO. RC20GF242J	5-3, SH. 1
R125		RESISTOR: 81349 NO. RC20GF621J	5-2
R126		RESISTOR: 81349 NO. RC20GF750J	5-2
R127		RESISTOR: 81349 NO. RV4NAYSG501A	3-1
S101		SWITCH, ROTARY: 4 POLE, 2 POSITION; 71590 NO. PA1012	3-1
S102		SWITCH, ROTARY: 8 POLE, 3 POSITION; 71590 NO. PA1026	3-1
S103		SWITCH, ROTARY; SAME AS S102	3-1
S104		SWITCH: 96906 NO. MS25098-23	3-1
TB100		PRINTED CIRCUIT BOARD: 06181 NO. B2177	5-2
T101		TRANSFORMER, MIXER: 06181 NO. C2170-1	5-2
Т102		TRANSFORMER, MIXER: 06181 NO. C2170-2	5-2

IF AMPLIFIER, C2127

2	AMPLIFIER, IF: 06181 NO. C2127	5-2
C201	CAPACITOR: 81349 NO. CK63AW103K	5-3, SH. 1
C202	CAPACITOR: SAME AS C201	5-3, SH. 1
C203	CAPACITOR: 81349 NO. CK62AW472K	5-3, SH. 1
C204	CAPACITOR: 81349 NO. CK62AW332K	5-3, SH. 1
C206	CAPACITOR: SAME AS C201	5-3, SH. 1
C207	CAPACITOR: SAME AS C203	5-3, SH. 1

TABLE 6-1. MAINTENANCE PARTS LIST (Cont)

IF AMPLIFIER, C2127 (Cont)

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG.
-	NOTES	NAME AND DESCRIPTION	NO.
C208		CAPACITOR: SAME AS C204	5-3, SH. 1
C210		CAPACITOR: SAME AS C201	5-3, SH. 1
C211		CAPACITOR: 81349 NO. CK62AW472K	5-3, SH. 1
C212		CAPACITOR: SAME AS C204	5-3, SH. 1
E7		TERMINAL, TEFLON: SAME AS E11	5-2
E8		TERMINAL, TEFLON: SAME AS E11	5-2
J202		CONNECTOR: SAME AS J104	5-2
J203		JACK, OUTPUT: 06181 NO. C2152	3-1
J204		CONNECTOR: SAME AS J104	5-2
L201		INDUCTOR, VARIABLE: 1.80 - 3.00 UH; 71279 NO. 3370-10	5-3, SH. 1
L202		INDUCTOR, VARIABLE: SAME AS L201	5-3, SH. 1
L203		INDUCTOR, VARIABLE: SAME AS L201	5-3, SH. 1
MP1		TOOL, TUNING: 06181 NO. C2734-2	5-2
P202		CONNECTOR: SAME AS P105	5-2
P204		CONNECTOR: SAME AS P105	5-2
Q201		TRANSISTOR: 81349 NO. 2N1309	5-3, SH. 1
Q202		TRANSISTOR: SAME AS Q201	5-3, SH. 1
Q203		TRANSISTOR: SAME AS Q201	5-3, SH. 1
R201		RESISTOR: 81349 NO. RC20GF273J	5-3, SH. 1
R202		RESISTOR: 81349 NO. RC20GF103J	5-3, SH. 1
R203		RESISTOR: 81349 NO. RC20GF680K	5-3, SH. 1
R204		RESISTOR: 81349 NO. RC20GF561K	5-3, SH. 1
R206		RESISTOR: SAME AS R201	5-3, SH. 1
R207		RESISTOR: SAME AS R202	5-3, SH. 1
R208		RESISTOR: SAME AS R204	5-3, SH. 1
R209		RESISTOR: SAME AS R203	5-3, SH. 1
R210		RESISTOR: SAME AS R201	5-3, SH. 1
R211		RESISTOR: SAME AS R202	5-3, SH. 1
R212		RESISTOR: SAME AS R204	5-3, SH. 1

IF AMPLIFIER, C2127 (Cont)

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG. NO.
R213		RESISTOR: 81349 NO. RC20GF220J	5-3, SH. 1
R214		RESISTOR: 81349 NO. RC20GF201J	5-3, SH. 1
TB200		PRINTED CIRCUIT BOARD: 06181 NO. C2129-1	5-2

POWER SUPPLY, C2122

		
3	POWER SUPPLY: 06181 NO. C2122	5-2
CA301	CABLE ASSEMBLY, POWER: 06181 NO. B2153	
CA301P303	CONNECTOR: 96906 NO. MS3106A14S7S	5-1
CA301P304	CONNECTOR: 81349 NO. UP121M	5-1
CA301W301	CABLE: 81349 NO. C0-03LG (3/18) 0260	
CR301	SEMICONDUCTOR DEVICE: 81349 NO. 1N972B	5-3, SH. 2
CR302	SEMICONDUCTOR DEVICE: 81349 NO. 1N966B	5-3, SH. 2
CR303	SEMICONDUCTOR DEVICE: 81349 NO. 1N538	5-3, SH. 2
CR304	SEMICONDUCTOR DEVICE: SAME AS CR303	5-3, SH. 2
CR305	SEMICONDUCTOR DEVICE: SAME AS CR303	5-3, SH. 2
CR306	SEMICONDUCTOR DEVICE: SAME AS CR303	5-3, SH. 2
C301	CAPACITOR: 81349 NO. CE51E501G	5-2
C302	CAPACITOR: 81349 NO. CL65BK50MP3	5-3, SH. 2
C303	CAPACITOR: SAME AS C302	5-3, SH. 2
DS301	LAMP: 96906 NO. MS25252NE2D	3-1
E1	TERMINAL, TEFLON: SAME AS E11	5-2
E2	TERMINAL, TEFLON: SAME AS E11	5-2
E3	TERMINAL, TEFLON: SAME AS E11	5-2
E4	TERMINAL, TEFLON: SAME AS E11	5-2
F301	FUSE, CARTRIDGE: 1/4 AMP, 250 V; 71400 NO. 3AG	3-1
F302	FUSE, CARTRIDGE: SAME AS F301	3-1
J303	CONNECTOR: 96906 NO. MS3102A14S7P	3-1
Q301	TRANSISTOR: 81349 NO. 2N297A	5-2
Q302	TRANSISTOR: SAME AS Q301	5-2
R301	RESISTOR: 81349 NO. RC20GF392K	5-3, SH. 2

ORIGINA L

POWER SUPPLY, C2122

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG. NO.
R302		RESISTOR: SAME AS R301	5-3, SH. 2
S301		SWITCH, ROTARY: 2 POLES, 5 SECTIONS; 27191 NO. 399713JC	3-1
TB300		PRINTED CIRCUIT BOARD: 06181 NO. C2119-2	5-2
TP301		JACK, TIP: 83330 NO. 1505-102	5-2
T301		TRANSFORMER: 81349 NO. TF4RX02EA	5-2
XC301		SOCKET: 81349 NO. TS101P01	5-2
XDS301		LIGHT, INDICATOR: ACCOMODATES NEON LAMP, P/N MS25252NE2D; 72619 NO. LH74LC130M	5-2
XF301		FUSEHOLDER: ACCOMODATES 1/4 AMP, 3AG FUSE; 71400 NO. FHN26G	5-2
XF302		FUSEHOLDER: SAME AS XF301	5-2

OSCILLATOR, C2132

4	OSCILLATOR: 06181 NO. C2132	5-2
m 404		
CR401	SEMICONDUCTOR DEVICE: 81349 NO. 1N4800A	5-3, SH. 2
CR402	SEMICONDUCTOR DEVICE: 81349 NO. 1N962B	5-3, SH. 2
CR403	SEMICONDUCTOR DEVICE: 81349 NO. 1N755A	5-3, SH. 2
C401	CAPACITOR, FIXED, CERAMIC DISC: 470 PF, $\pm 5\%$, 1000 WVDC; 56289 NO. 10TCUT47	5-3, SH. 2
C402	CAPACITOR: 81349 NO. CM20E182J	5-3, SH. 2
C403	CAPACITOR: 81349 NO. CM15C180J	5-3, SH. 2
C404	CAPACITOR: 81349 NO. CM20E102J	5-3, SH. 2
C406	CAPACITOR, FIXED, CERAMIC DISC: 0.1 UF, $\pm 20\%$ 50 WVDC; 56289 NO. TG-P10	5-3, SH. 2
C407	CAPACITOR: SAME AS C201	5-3, SH. 2
C408	CAPACITOR: SAME AS C406	5-3, SH. 2
C409	CAPACITOR: SAME AS C404	5-3, SH. 2
C410	CAPACITOR: SAME AS C201	5-2
C411	CAPACITOR: SAME AS C406	5-3, SH. 2
C412	CAPACITOR: 81349 NO. CM06E561J	5-2
C413	CAPACITOR: 81349 NO. CM06E821J	5-2
E5	TERMINAL, TEFLON: SAME AS E11	5-1

OSCILLATOR, C2132

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG. NO.
E6	-	TERMINAL, TEFLON: SAME AS E11	5-1
J402		CONNECTOR: SAME AS J104	5-2
J403		CONNECTOR: SAME AS J105	3-1
L401		INDUCTOR, VARIABLE: 0.7 - 1.4 UH; 06181 NO. B2137A	5-2
L403	•	INDUCTOR, FIXED: 5MH; 71895 NO. 2500-62	5-2
P402		CONNECTOR: SAME AS P105	5-2
Q401		TRANSISTOR: SAME AS Q201	5-3, SH. 2
Q402		TRANSISTOR: SAME AS Q201	5-3, SH. 2
Q403		TRANSISTOR: SAME AS Q201	5-3, SH. 2
R401		RESISTOR: 81349 NO. RC20GF474K	5-3, SH. 2
R402		RESISTOR: 81349 NO. RC20GF753K	5-3, SH. 2
R403		RESISTOR: 81349 NO. RC20GF473K	5-3, SH. 2
R404		RESISTOR: VARIABLE: 10 TURNS, 50K; 12697 NO. 26JA50K	3-1
R405	1	RESISTOR, 81349 NO. RC20GF102K	5-3, SH. 2
R406		RESISTOR: 81349 NO. RC20GF562J	5-3, SH. 2
R407		RESISTOR: 81349 NO. RV4LAYSB253A	5-2
R408		RESISTOR: 81349 NO. RC20GF223K	5-3, SH. 2
R409		RESISTOR: 81349 NO. RC20GF822K	5-3, SH. 2
R410		RESISTOR: 81349 NO. RC20GF124K	5-3, SH. 2
R411		RESISTOR: 81349 NO. RC20GF272K	5-3, SH. 2
R412		RESISTOR: 81349 NO. RC20GF241J	5-3, SH. 2
R414		RESISTOR: 81349 NO. RC20GF333J	5-2
R415		RESISTOR: 81349 NO. RC20GF105J	5-3, SH. 2
TB400A		PRINTED CIRCUIT BOARD: 06181 NO. C2142-1	5-2
тв400в		PRINTED CIRCUIT BOARD: 06181 NO. C2142-4	5-2
		.= ,	
L	<u> </u>		1

CABLE ASSEMBLIES

REF DESIG	NOTES	NAME AND DESCRIPTION	FIG. NO.
W1	. ,	CABLE ASSEMBLY: 06181 NO. 2152W1	5-2
W2		CABLE ASSEMBLY: 06181 NO. 2152W2	5-2
w3		CABLE ASSEMBLY: 06181 NO. 2152W3	5-2
W4		CABLE ASSEMBLY: 06181 NO. 2152W4	5-2
W5		CABLE ASSEMBLY: 06181 NO. 2152W5	5-2
W6		CABLE ASSEMBLY: 06181 NO. 2152W6	5-2

TABLE 6-2. LIST OF MANUFACTURERS

MFR CODE	NAME	ADDRESS
06181	Probescope Co., Inc.	211 Robbins Lane Syosset, N. Y. 11791
12615	U.S. Terminals, Inc.	7504 Camargo Road Cincinnati, Ohio 45243
12697	Clarostat Mfg. Co., Inc.	Lower Washington Street Dover, N. H. 03820
27191	Cutler-Hammer, Inc. Power Distribution and Control Division	4201 N. 27th St. Milwaukee, Wis. 53216
56289	Sprague Electric Co.	Marshall Street North Adams, Mass. 01247
58474	Superior Electric Co.	383 Middle Street Bristol, Conn. 06010
71279	Cambridge Thermionic Corp.	445 Concord Ave. Cambridge, Mass. 02138
71400	Bussmann Mfg. Div. of McGraw-Edison Co.	2536 W. University St. St. Louis, Mo. 63017
71590	Globe-Union, Inc. Centralab Division	P.O. Box 591 Milwaukee, Wis. 53201
71895	Delavan Mfg. Co.	811 Fourth Street West Des Moines, Iowa 50265
72619	Dialight Corp.	60 Stewart Ave. Brooklyn, N.Y. 11237
81349	Military Specification	
83330	Herman H. Smith, Inc.	812 Snediker Ave. Brooklyn, N.Y. 11207
96906	Military Standards	